
HÄFELE

A Parallel arm bracket

- Converts fig 1 closer to fig 66
- Note: Parallel arm brackets are included with all closers shown on pages 6, 7, 15, 16, 19, 22 and 23 (item A) but not included with TS 1000 closer shown on page 23 (item B)
- Electro-lated mild steel*

Finish	Cat. No.	
To suit closers on pgs 6, 7, 15, 16, 19, 22, 2		
Silver	931.16.329	
Satin stainless steel*	931.16.320	
Polished stainless steel*	931.16.326	
Polished brass	931.16.328	
To suit closers on page 23 (item B):		
Silver	931.16.459	

Order qty: 1 pc



Bracket 931.16.329 shown




B Architrave bracket

- To suit closers on pages 6, 7, 15, 16, 19 and 22
- To be used where a fig. 1 bracket would not be acceptable or practicible (i.e. decorative architrave)
- Electro-plated mild steel*

Finish	Cat. No.
Silver	931.16.439
Satin stainless steel*	931.16.430
Polished stainless steel*	931.16.436
Polished brass*	931.16.438

Order qty: 1 pc





Silver finish shown




C Overpanel bracket

- To suit closers on pages 6, 7, 15 and 16
- To be used where overpanels to doors are specified
- Electro-plated mild steel*

Ziooti o piatoa i i iii a otooi			
	Finish	Cat. No.	
	Silver	931.16.449	
	Satin stainless steel*	931.16.440	
	Polished stainless steel*	931.16.441	_

Order qty: 1 pc





D Hold open arm

- To suit closers on pages 6, 7, 15 and 16
- Converts standard closer to hold open engageable/disengageable
- NOT to be used on fire doors
- Steel. Silver sprayed

	, ,	
Cat. No.		940.01.975

Order qty: 1 pc







E Hold-open arm

- To suit closers on pages 19, 22 and 23
- Converts standard closer to hold open
- NOT to be used on fire doors
- Steel. Silver sprayed

Cat. No. 931.16.689

Order qty: 1 pc





TCH-AI 2008, HUK. Dimensional data not binding. We reserve the right to alter specifications without notice.