

FOOT OPERATED DOOR OPENERS

The pedal is mounted underneath the front edge of the cabinet floor with the counterplate on the inside of the door.


Light foot pressure on the pedal releases the magnetic catch and causes the rubber expander cord between the cabinet floor and the base shelf to pull base shelf and door forward out of the cabinet.



Door openers do not work with systems that incorporate soft close mechanisms



Foot pedals for use with waste bins, designed for door front fixing cabinets



- > Includes pedal with magnetic catch, counterplate and draw spring
- > Plastic aluminium effect metallic paint coated pedal with black lacquered steel counterplate
- > Note: Not for use in commercial high volume use such as doctors and dentist surgeries
- > Order qty: 1 pc



Usage	Cat. No.
For medium sized drawer mount bins	502.15.260
For tall sized bins	502.15.250



Other door operating systems are available



Foot pedal for hinged door cabinets is shown on page 148



Sensomatic door opening system, ideal for waste bin drawer systems is shown on page 149