


FOOT OPERATED DOOR OPENER

Two types of door opener are available; for hinged or front mounted doors. Ideal for cabinets with waste bins for when hands are full or dirty, or for any cabinet where quick and easy access is required, with a simple kick to open action.

Foot operated door opener, for hinged door cabinets




- > For hinged door cabinets
- > Includes pedal with magnetic catch, counterplate and spring-loaded roller arm
- > Light foot pressure on the pedal releases the magnetic catch and causes the spring-loaded roller arm to push the door open. The waste bin does not swing out with the door unless the bin is door mounted or has a follower fitted
- > Brown plastic pedal, black lacquered steel counterplate and white plastic spring loaded roller arm
- > Note: Not for use in commercial high volume use such as doctors and dentist surgeries
- > Order qty: 1 pc



Door openers do not work with systems that incorporate soft close mechanisms

Cat. No.	
Door opener	502.15.033

Foot pedal for light weight bins, for door front fixing cabinets



- > For door front fixing cabinets
- > Includes pedal with magnetic catch, counterplate and draw spring
- > Plastic aluminium effect metallic paint coated pedal with black lacquered steel counterplate
- > Note: Not for use in commercial high volume use such as doctors and dentist surgeries
- > Order qty: 1 pc



Only suitable for use with Hailo Tandem bins

Cat. No.	
Usage	For medium sized drawer mount bins
	502.15.260