

## FESTOOL PROTECTION PADS


## Festool protection pad PP-STF, Ø 125 mm



- > For protecting the sanding pad when using abrasive net
- > Suitable for RO 125, ES 125, ETS 125, ETSC 125, ETS EC 125, LEX 125
- > Order qty: 1 pc = 2 pads

| Size     | Cat. No.   |
|----------|------------|
| Ø 125 mm | 005.24.723 |

## Festool protection pad PP-STF, Ø 150 mm



- > For protecting the sanding pad when using abrasive net
- > Suitable for RO 150, ES 150, ETS 150, ETS EC 150, LEX 150, WTS 150
- > Order qty: 1 pc = 2 pads

| Size     | Cat. No.   |
|----------|------------|
| Ø 150 mm | 005.24.722 |

## Festool protection pad PP-STF, 80 x 133 mm



- > For protecting the sanding pad when using abrasive net
- > Suitable for RTS 400, RTSC 400, RS 400, RS 4, LS 130
- > Order qty: 1 pc = 2 pads

| Size        | Cat. No.   |
|-------------|------------|
| 80 x 133 mm | 005.22.274 |

## Festool protection pad PP-STF, Delta, 100 x 150 mm



- > For protecting the sanding pad when using abrasive net
- > Suitable for DTS 400, DTSC 400, DS 400
- > Order qty: 1 pc = 2 pads

| Size               | Cat. No.   |
|--------------------|------------|
| Delta 100 x 150 mm | 005.26.391 |