


- > The DuoBlade is part of the innovative DuoLine and therefore consists of different components, which enable the best possible performance.
- > The self-drilling tip allows a clean and effective drilling procedure.
- > The fixing is screwed in the pre-positioned installation with the (cordless) screwdriver setting tool flush to the surface of the gypsum plasterboard.
- > The fischer DuoBlade is adapted for wood, metal and chipboard screws from 4 to 5 mm thickness as well as different hooks and eye screws. Consequently, it is universally suitable for fixing e.g. smoke detectors, curtain rods and shutters securely and quickly.
- > The DuoBlade is placed in the plasterboard with a conventional PZ 2 drive. No special setting device is required.

Fischer Plasterboard fixing DuoBlade S



- > High torque when anchor is installed for the feelgood-factor and an optimum feeling when setting
- > Anti rotation lock prevents from spinning in the drill hole
- > Use of commercially available hooks, screws and eyelets
- > PZ2 drive - same drive for plug and screw
- > Self-drilling plasterboard plug for fast and easy installation



Anchor length	Anchorage depth	Min. thickness to supporting layer	Cat. No.	Order Qty
Screws included				
44 mm	9.5-25 mm	50 mm	051.69.003	20
Screws not included				
44 mm	9.5-25 mm	50 mm	051.69.002	40