



PUSH-LOCK KNOBS AND ROSETTES

- > Push-Lock knobs and rosettes can be purchased to suit particular door thicknesses
- > If a rim lock with two spindles is used, for opening the door from both sides, order 2x knobs and 1x rosette
- > With a two spindle lock, the push knob on the front of the door closes almost flush to the door but a knob used at the back of the lock, on the second spindle, never closes flush to the lock case or door



For use with Push-Locks locks, shown on pages **8.91-93**

Push-Lock knob




- > For 13-19 mm door thicknesses
- > Plastic
- > Order qty: 1 pc



Order rosette separately, shown on page **8.97**

Finish	Cat. No.
Matt nickel-plated	229.01.677
Polished chrome-plated	229.01.220
Matt black, RAL 9005	229.01.300

Push-Lock knob



- > For 13-19 mm door thicknesses
- > Brass
- > Order qty: 1 pc



Order rosette separately, shown on page **8.97**

Finish	Cat. No.
Matt nickel-plated	229.01.280