

BENCH SEAT HINGE


For wooden seat panels. No separate hinge connection required.



Bench seat hinge, with or without spring





With spring, for panel weights up to 12 kg



Without spring, for lightweight panels

- > Opening angle 95°
- > Area of application: Joint designed for safe lift-up of seat panel
- > Opening angle restraint: The opening stop in the hinge joint prevents the seat panel from butting against the fitting
- > With spring; for panel weights up to 12 kg
- > Without spring; for lightweight panels
- > The spring for panel weight 12 kg provide optimum weight compensation and allow opening with ease
- > Large swivel range to the front (110 mm) allows lifting up seat panels even with thick padding
- > A gap between seat panel and backrest is not required
- > No separate hinge connection required
- > Blue galvanized steel
- > Order fixing screws separately
- > Order qty: 1 pair



With spring	Cat. No.
Suitable for panel weight up to 12 kg	643.01.525
Without spring	Cat. No.
Suitable for lightweight panels	643.01.500