

SIM592B

**86cm Slider Touch Control MultiZone Induction Hob,
Angled Edge Glass**

EAN13: 8017709193461

- 5 "full power" induction zones including:
- Left: Ø 180mm, 1.85kW – booster 2.5kW
- Rear Left: Ø 180/230mm, 1.85kW – booster

2.5kW

**The two zones on the left can be combined to create one MultiZone: Ø 180/385mm,
1.8kW - booster 5kW**

- Centre: Ø 300mm, 2.8kW – booster 5.4kW
- Rear right: Ø 180, 1.85kW – booster 2.5kW
- Front right: Ø 180, 1.85kW – booster 2.5kW
- The two zones on the right can be combined to create one MultiZone: Ø 180/385mm,
1.8kW

– booster 5.0kW



Each MultiZone automatically detects the size and position of the pots and pans, and heats up the exact spots where they stand, providing optimum heat distribution and efficiency. This allows several pans to be used at once, large or small, offering freedom of placement and greater flexibility.

- Easy clean glass
- 4 independent boosters(P)
- Individual timers for each zone
- 12 power levels
- Visual display to show power level/residual heat/countdown cooking time
- 2 Quick set levels - for medium or low cooking
- Pre-heat mode
- Auto pan recognition and adjustment to pan size
- Overheating and Overflow protection system
- Protection against auto-start up
- End of cooking acoustic alarm
- Automatic safety cut-out
- Child safety lock
- Nominal power 10.2kW
- Consult a qualified electrician for power supply wiring requirements

**NB: only pans with a ferrous (magnetic) base are suitable
for induction hobs.**

Functions





Multizone:

allows several pans to be used at once, large or small, offering freedom of placement and greater flexibility



Child lock:

some models are fitted with a device to lock the programme/cycle so it cannot be accidentally changed.



Touch controls:

Easy to use touch controls allow the appliance to be programmed at the touch of a button.



Time elapsed:

shows how long the cooking zone has been in use



Power booster:

option allows the zone to work at full power when very intense cooking is necessary.



Quick Start:

When the Quick Start function is selected, the chosen temperature is reached faster. The heating element works at maximum power until the right temperature is reached.



Timer:

All ceramic hobs have a timer which automatically ends cooking after a preset time.

